

# User Guide

SDP Group 15-H

Emilia Bogdanova  
Patrick Green  
Julijonas Kikutis  
David McArthur  
Aseem Narang  
Ankit Sonkar

The University of Edinburgh

# 1 Installation

## 1.1 Cloning the repository and setting up

To clone the repository, execute in terminal:

```
$ git clone https://github.com/julijonas/venus.git
```

Then go to the root directory of the project and create a Python virtual environment which will contain a local copy of the libraries needed for this project:

```
$ cd venus
$ virtualenv --system-site-packages env
$ source env/bin/activate
```

Install the *pyserial* library which is used to send data to Arduino through RF stick:

```
$ pip install pyserial
```

To set the persistent radio chip configuration for a new Arduino board, connect to the PC with an USB cable, execute `screen /dev/tty0` in terminal, and enter the following commands substituting the appropriate group number and radio frequency band:

```
+++
ATID0015
ATAC
ATRP1
ATAC
ATCN80
ATAC
ATWR
ARDN
```

To close `screen`, press *Ctrl+A* and then *X*. The identical steps have to be performed for a new RF stick.

To program the Arduino to receive and execute messages, open the Arduino IDE by executing `arduino` in terminal. You'll need to add three libraries which can be found under `arduino/` in the project directory: *ArduinoSerialCommand*, *SDPArduino*, *SimpleTimer*. In order to add a library, go to `Sketch -> Import Library... -> Add Library...` and choose the library directory you want to import. Then open the Arduino file `arduino/arduino.ino` using `File -> Open...` and upload it to the board using `File -> Upload`.

## 2 Hardware overview

### 2.1 Components

#### 2.1.1 Motions

The robot has four holonomic wheels, which are placed in the middle of each side of the robot. The holonomic motion allows the robot to move in any direction. All wheels are powered by NXT motors.

The grabber consists of two symmetric parts resembling arms (Figure ??). It is powered by a single Power Functions Medium motor, which is connected to a symmetric gear system. The latter is used to ensure both arms are opened and closed at the same time. The kicking works in the following way.

#### 2.1.2 Senors

Each NXT motor is connected to the rotary encoder board (Figure ??). The connections in the anticlockwise order from the top are: the I2C bus to the Arduino, back right motor, back left motor, front left motor, and front right motor. Using this board the information about the amount of rotations the motor has performed since the last query is available for the Arduino code as a separate integer for every motor. Every 5 ms the board is queried whether the target value has been reached. After the average of the rotary values of all four motors becomes greater or equal to the target value, the motors are stopped.

The light sensor is located above the grabber (Figure ??). It is used to check whether the robot has successfully acquired the ball after grabbing. The sensor returns a value associated with the reflected colors in its line of sight. Then the Arduino compares that value to a predefined threshold corresponding to the red ball. Sometimes a white line inside the pitch can be mistaken for the ball due to their similar sensor values.

### 2.2 Usage

#### 2.2.1 Preparation for the match

In order to turn the robot on, connect the battery pack to the power board. The pack consists of 10 AA rechargable batteries. Normally one fully charged battery pack would last for 7-10 minutes after which noticeable under-turning will occur. Ensure that the battery back is placed directly in the center as a change in weight distribution can cause the need for a recalibration of moving , turning and kicking.

#### 2.2.2 RF stick

To communicate with Venus the RF stick should be connected to the machine you are running the commands from. Then after performing steps described in "Running instructions" section, you will be able to operate the robot.

If you make any changes in the Arduino code, you need to upload them before running the commands (uploading instructions can be found in the "Installation" section above). Uploading can be done either via RF stick or the USB cable connected to the Arduino board.

## 3 Software overview

### 3.1 Running instructions

Run the following command in the terminal from the project root directory if it has not been done already to enable the Python virtual environment which contains the required libraries:

```
$ source env/bin/activate
```

In order to set the room containing the pitch, colors of the robot, and side of the goal, change the hard-coded parameters of *init* method in *control/holonomic.py* as detailed in Table 1. For example, if the room is 3.D04, the robot has the yellow team color and one green-coloured dot, and the robot is defending the goal closer to the computers, the line would be:

```
def init(self, room_num=1, team_color='yellow', our_color='green',
        computer_goal=True):
```

Room	room_num	team_color	our_color	computer_goal
3.D03	0	'yellow'	'green'	True
3.D04	1	'blue'	'pink'	False

Table 1: Allowed parameters for the *init* method

Then ensure that the RF stick is plugged in. To start the application, make connections to the RF stick, vision feed, and get access to the command prompt, execute the following line:


```
$ python main.py
```

**NB:** In case you make changes to the Arduino code, you should upload your changes to the board as detailed in Section 1.1.

Then the operator of the robot can start entering the commands. The main command is **hs** which starts the strategy. The listing of all commands is provided in Table 2.

### 3.2 Calibration of the vision

**Camera capture settings:** As the images appearance can change between computers you may need to slightly adjust the capture settings. This simple calibration is always more preferable than going for a complete calibration. In



Constantly run the strategy state machine	<code>hs</code>
Output a picture of the potential field of the state	<code>map state_name</code>
Perform a holonomic motion (angles in degrees)	<code>move direction_angle turn_angle</code>
Move forward (in cm, negative means backward)	<code>f distance</code>
Rotate clockwise (in degrees, negative means anti-clockwise)	<code>c angle</code>
Stop all motors	<code>s</code>
Open the grabber	<code>o</code>
Close the grabber	<code>g</code>
Perform a spin kick	<code>ee</code>
Print world state	<code>w</code>
Query light sensor	<code>query_ball</code>
Pass the ball to the teammate	<code>pass_ball</code>
Catch the ball coming from the teammate	<code>catch_ball</code>
Kick the ball to the goal	<code>goal</code>
Exit the application	<code>exit</code>

Table 2: Commands available for the operator of the robot

which case use the slider bars that pop up on the vision feed each corresponding to a percentage see the image to the left. Brightness and contrast can help make the colors more distinguishable and a larger contrast than brightness works better. Reducing the saturation can help remove unwanted spots from the blurred colors created by the white lines.


**Color calibration:** To enter this mode the slider bar named calibration must be moved. The first step is to click and the terminal will outline everything that can be calibrated, see image bellow. Each one is activated by pressing a key outlined bellow. For colors it is advised to click on that coloured spot a few times. Be sure to check the terminal to make sure your on the right color. For pitch dimensions a description of how to click each object is added in the terminal. The general convention is any order to mark the goals and for shapes start at the top left and work clockwise. Once you ready to move on press the ESC key.



**Fine tuning the colors:** Once the ESC key has been pressed the color thresholds predicted from the clicking can be fine tuned. If nothing is seen it is advised to reduce saturation and value first before adjusting the hue values. The aim is to see as minimal of spots not in that color as possible and make the actual color as solid as possible. Press the ESC key to move on and eventually the original vision key will be brought up.

**Green and yellow:** As they can blend together easily it is important that they can be seen clearly so try to reduce the hue threshold of yellow and increase the hue threshold of green as much as possible.

**Red and pink:** Sometimes the ball cannot be found so if you enter the calibration and press ESC instantly you will only be adjusting reds thresholds. The tuning window for red requires you to adjust to separate ranges of values so make sure this is done to get as clear spot as possible. Its similarities with pink can be avoided after calibrating by adjusting the slider bars for the camera capture settings.



### 3.3 Handling

Handle the robot with care. It is advisable not to lose the top plate during the game. It can be secured properly to the robot using Blu-Tack.

#### 3.3.1 Calibration

Before playing a match, ensure that the spin-kick (goal command), going forward (f command), and turning (c command) are calibrated. It can be done by repeatedly executing the respective commands with different input values,



**Problem 5:** The Python application cannot connect to the RF stick because the RF stick has registered itself as `/dev/ttyACM1`.

**Solution:** Either close all programs that have handles to `/dev/ttyACM0` and reconnect the RF stick or change the `device_no` parameter in the `connect` method in `control/holonomic.py` to 1 and restart the Python application.

**Problem 6:** The robot is turning a smaller angle than 360 degrees.

**Solution:** Change the battery set to a fully charged one.

**Problem 7:** The commands are evidently sent but the robot does not move.

**Solution:** Power cycle the Arduino. If that does not help, change the battery set to a fully charged one.

**Problem 8:** The freshly charged batteries are hot.

**Solution:** Do not put such battery set into the Arduino as the motions will not be reliable. Wait for them to cool down and obtain another set instead.